



# A4 Debossing Back - Regular



## Notebooks: JPA4, ENV4

Note: The Brand Area can be moved anywhere within the Brandable Area.  
The Brandable Area starts 10mm away from the spine of the book.



DOTTED LINE WILL NOT APPEAR ON YOUR IMPRINTED ITEM