
A4 Debossing Back - Large



Notebooks: JPA4, ENV4

Note: The Brand Area can be moved anywhere within the Brandable Area. The Brandable Area starts 10mm away from the spine of the book.

